



If the tip on your adapter is not long enough to fit properly into your cell phone, you must remove the adapter spacer.



Step 1:

Locate the spacer on the adapter tip.



Step 2:

Slide the spacer towards the end of the adapter tip.



Step 3:

Remove the spacer and insert the tip into your cell phone.